

Defuse The Bomb

User Manual



Casecore Games © 2025
www.casecoregames.com

1. Important Safety Instructions ⚠

General Use

- Use the device only in dry, clean, and well-ventilated environments. Maintain minimum clearance of 10 cm (top, rear, and sides) for proper ventilation.
- Keep away from heat sources, direct sunlight, strong vibrations, and water.
- Do not place objects on top of the device or cover it with cloths, paper, or other materials that may obstruct ventilation.
- Always switch the device off before storing.
- Handle with care: although the enclosure is robust, strong impacts may damage internal components.

Power Supply & Charging

- The device contains a rechargeable lithium-ion battery (single cell, 3.7 V, 7000mAh).
- Charging input: 5 V DC, max. 1 A.
- Only charge the device with high-quality, certified USB chargers.
- ⚠ Do not connect this device directly to a mains power socket using only a USB cable without a certified charger.
- Do not leave the device permanently connected to a charger during long-term storage.
- Never use higher input voltage than specified. Doing so may cause fire, injury, or device damage.
- If the battery shows signs of swelling, leakage, or overheating, stop using the device immediately and contact the manufacturer.
- The battery is not user-replaceable. Attempting to open or replace it may cause hazards and void warranty.

Recycling & Disposal


- Electronic equipment must be collected and recycled separately in accordance with the **WEEE Directive (2012/19/EU)** and local laws.
- Do not dispose of this device with household waste
- Return the product to designated collection points for proper recycling and recovery.
- The internal lithium-ion battery must not be incinerated or placed in domestic waste.

Compliance & Legal Information

- EU Compliance: This product complies with the essential requirements of the RoHS Directive (2011/65/EU), and Low Voltage Directive (2014/35/EU).

2. Product specifications

Model name	Defuse the bomb
Dimensions (Width x Height x Depth)	47cm x 35cm x 16.5cm
Weight	7 kg
Tilt Range	45°
Operating Temperature	-5°C to 45°C
Operating Humidity	< 80%
Battery charge input power	5V DC
Battery capacity	7000 mAh



Manufacturer Information

- Manufacturer: **Room Jack Heroes Emil Cychylik**
- Address: **Jugosłowańska 20A, 70-842 Szczecin, Poland**
- Model: **Defuse the bomb**
- Contact: **Whatsapp +48 575 070 495 / hello@casecoregames.com**

CASECORE

1. Operating the Device

- **Power On:** Press the yellow/red **button labeled “Power”** on the front panel **twice quickly**.
- **Power Off:** Press the same button **three times**.
- Once powered on, the game will automatically load and start.

Settings edit codes:

While the game is going, type the codes on the **keypad** and press **#** to confirm them to edit following settings:

- **Code 00001** and **#** - to change time
- **Code 00002** and **#** - to change number of mistakes

Battery and Charging Instructions

Important:

This device contains a built-in **Li-ion battery**, which must be handled with care. Always follow all safety instructions listed in this manual when charging, storing, or operating the device.

Charging the Battery

1. To charge the battery, use the provided **USB cable** together with a standard USB charger (such as those used for phones or other 5 V devices). The charger is not included due to differences in electrical outlets worldwide.
 - Connect the **USB cable** to the input port on the side of the case.
 - Connect the other side of the USB **cable** to your charger.
2. Typical charge time for a full battery is around **8 hours**.

Checking Battery Level

1. Disconnect the charging cable.
2. Turn on the device.
3. The battery level indicator, located next to the charging port, will display the current charge status.

The indicator stages are as follows:



- **Red outline only** – Battery almost discharged (<25%)
- **1 bar** – ~25%
- **2 bars** – ~50%
- **3 bars** – ~75%
- **4 bars** – 75-100% (fully charged)