

CASECORE

game props for your events

Expander Case - Simon Says

User Manual



Casecore Games © 2024
www.casecoregames.com



Important safety instructions

- Before using the product, read these instructions carefully. Keep this document in a safe place for future reference.
- Only use this device in dry, clean and well ventilated places, minimum clearances for ventilation are top: 10cm, rear: 10cm, sides 10 cm.
- Keep the device away from any heat sources, vibrations, direct sunlight and water.
- Do not place any objects on top of the device, do not cover with cloths, paper or other materials that may obstruct heat radiation.
- Always make sure the device is powered off when storing.
- Do not plug this device directly into the wall socket with USB cable, as it may cause an electrical shock, fire, damage to the unit and/or personal injury.
- Do not use the device installed upside-down.
- Do not use force on any prop elements.
- This device should not be used by children without supervision of adults.
- Only input voltage specified for this unit can be used. Using higher voltage can be dangerous and may cause fire, damage the unit and/or personal injury. Cascore will not be held responsible for any damage resulting from the use of this unit with a voltage other than specified.
- Do not attempt to modify or fix this unit without contacting Cascore Games.
- The front panel of the unit should not be lifted without contacting Cascore Games.
- Don't leave the device powered when storing.
- **To power the device use a stable 5V DC / 1A power supply.**

1. Intended use of the device

This device is designed as an event game prop and should not be used in any other way.

1.1 Handle with care

The device was made as durable and robust as possible but fragile electronic connections inside might be damaged on serious impacts, therefore move it with care.

1.2 Specifications of the unit

Model	Expander Case - Simon Says
Dimensions (Width x Height x Depth)	270 x 246 x 124 mm
Weight	3 kg
Tilt Range	45°
Operating Temperature	0°C to 35°C
Operating Humidity	< 80%
Input power	5V DC / 1A



CAUTION! DO NOT PUT IN DOMESTIC WASTE.

This marking means that the product cannot be discarded with other wastes. To prevent potential damage to the environment or health, used up the product must be recycled. In accordance with applicable law, unfit electrical equipment must be collected separately, at specially designated places for them to be processed and re-processed, based on applicable environmental protection standards.



2. Powering the prop

To use the device, 5V DC power needs to be connected to the slot at the back of the prop. Normally an external power bank along with USB cable is used, so the players can power the case by themselves during the game as an additional task to perform.

If you have the option for your Explorer Case you might have a power output slot, so the players can use the power from the main case to power up the add-ons. The Explorer Case Pro always has the power output slot.

3. Operating the device

This prop is a stand alone mini game.

- Players have to go through 5 stages of simon says type game.
- The game starts with 3 presses to follow and increment by 1 with each stage.
- Inside there is a buzzer that will beep with a different sound for each button pressed.
- The LED tube has 5 LEDs inside for each stage, they can be either red or green, the colors can't be changed.
- Every time the new game starts or players make a mistake a new sequence is generated randomly.
- Sometimes it might be very simple due to the random nature of only 4 buttons, it is normal.
- After solving all 5 stages a code will be displayed on the screen.

4. Changing the final code

1. Turn off the device.
2. Press the yellow button and keep it pushed.
3. Power the device, it should enter the edit mode right away.
4. Use 4 buttons to increment the digits on the display.
5. Turn the device off to save the code.

5. Additional support

If you have more questions or you are having troubles setting up your prop, you can contact us here:

<https://casecoregames.com/contact-us>

Thank you for buying our products!

Emil Cychylik

Lead Designer at Cascore Games